


Layout diagram leXsolar-ESave Ready-to-go
 Item-No.1502
 Bestückungsplan leXsolar-ESave Ready-to-go
 Art.-Nr.1502




- 1** L2-06-035 Infrared-Thermometer 4970
L2-06-035 Infrarot-Thermometer 4970
- 2** L2-06-039 Arexx temperature + humidity sensor
L2-06-039 Arexx Temperatur + Luftfeuchtsensor
- 3** L2-06-038 Arexx base station
L2-06-038 Arexx Basisstation
- 4** L2-06-040 Arexx outdoor temperature sensor
L2-06-040 Arexx Außen-Temperatursensor
- 5** 3xL2-06-037 Arexx temperature sensor
3xL2-06-037 Arexx Temperatursensor

Optional expansions
 Optionale Erweiterungen

1500-01 Expansion CO₂ Sensor consisting of:
 1500-01 Erweiterung CO₂ Sensor bestehend aus:

- x1** L2-06-042 Arexx CO₂ Sensor
L2-06-042 Arexx CO₂ Sensor

Version number
 Versionsnummer



Layout diagram leXsolar-ESave Ready-to-go
 Item-No.1502
 Bestückungsplan leXsolar-ESave Ready-to-go
 Art.-Nr.1502



- 6 L2-06-036 Energy meter
L2-06-036 Energiekostenmessgerät
- 7 L2-06-034 Luxmeter
L2-06-034 Luxmeter
- 8 L2-06-054 Power supply
L2-06-054 Netzteil
- 9 L2-06-041 Flowmeter
L2-06-041 Durchflussmengenmessgerät
- 10 L3-03-016 leXsolar-CD
L3-03-016 leXsolar-CD